

Room adaptation for Jore & Dingle

The ideal way is to first try out the optimal placement. That is, find the point where the speaker sounds most harmonious.

Step 2 is then to try out the optimal attenuation of the speaker's bass port.

In a completely free placement without any wall behind the speaker, it may be best without any attenuation at all.

When "in-tuned" placement relatively close to the wall, we have had good results with attenuation as shown below, although we recommend that your speakers be optimized for your room!

Dingle: 16cm internal length (6 layers 2.5cm wide strips)

Jore: 9.5 cm internal length (5 layers 2 cm wide strips)

Testing:



Start by pushing the damping in just a few cm, and then push in a few cm at a time and listen until the position where the speaker really starts to "play and sing" Try to make it as similar as possible for both speakers.

If you want to make it neat, the excess (minus 0.5cm) can be cut off. But it will then be difficult to adjust, so it is practical to leave 2-3 cm so that you can get hold easily for possible future adjustments.