Manual for klångedang Jore

Connections passive use;

Red input + Black input -

Active use

For active use, the backplate needs to be removed, and the passive crossover must be disconnected. For permanent active operation, it is recommended that the passive crossover be removed. In case of demo in store, it may remain. Option: nameplate for active use. **Note no connection to red or black!**

Connections active use: Green treble + Blue treble -

Yellow bass + White bass -

Double check connections for active version! Wrong connection will damage the drive units. Do not switch on the amplifier before correctly connected to the speakers!

Note: When Jore is new, several re-tightenings of the drive units are needed. Tighten at installation and then weekly as needed. Torque 1.4Nm is adequate if you have such a tool.

Jore is designed to be placed relatively close to the wall. But you have to listen for finding the optimally distance in each room!

Adjust the stands spikes so the speaker is in level. Tighten then the nuts. Your dealer can advice regarding floorsavers if you want to protect the floor.

Technical Specifications	
Product Name	Jore
Product No	K1
Current version	See website.
principle	2-way
x-over	directly connected series filter 2nd order
Frequency range	50-30 000 Hz
Sensitivity	89dB / 4 ohms
Min impedance	3.5 ohm
Power music	80 Watt
Height	36.5cm
Width	21cm
Depth	30.6cm

Manufactured in Sweden, under license by

Tonläget HiFi AB Aschebergsgatan 15 411 27 Göteborg Designed by: Anders Simonsson





Recycled as consumer electronics. Complies with the EU's General Product Safety Directive

Safety information

Klångedang Jore is not magnetically shielded, so you should not place credit cards with magnetic strips, cassette tapes, videotapes, or other magnetic storage media closer than 30cm from the speakers. For long-term storage we recommend 50 cm spacing.

If the speakers are placed where there is a risk a child or animal by accident could roll down the speakers – We recommend You prevent this by securing a safety cord with a hook attached to the back of the speaker box and the other end attached to the wall.



klångedang Jore Manual and safety information